

Steps to Connect the SMPS in a New Gaming PC

1. **Install the SMPS in the PC Case**
 - Secure the SMPS (Power Supply Unit) in the case using screws.
 - Ensure the power switch is OFF before making connections.
2. **Connect Power to the Motherboard**
 - Use the **24-pin ATX motherboard power cable** from the SMPS.
 - Plug the **24-pin ATX connector** into the matching socket on the motherboard until it clicks into place.
3. **Connect CPU Power**
 - Use the **4+4-pin (8-pin) EPS/CPU power cable**.
 - Connect it to the **CPU_PWR** socket near the processor on the motherboard.
4. **Connect Power to the Graphics Card (GPU)**
 - Use the **PCIe 6-pin, 8-pin, or 6+2-pin power cable** from the SMPS.
 - Plug the connector(s) into the graphics card's power socket(s) according to its requirements.
5. **Connect Power to Storage Devices**
 - Use **SATA power cables** from the SMPS.
 - Connect the **SATA power connectors** to SSDs, HDDs, or optical drives.
6. **Connect Other Accessories (if required)**
 - Use **Molex connectors** for older fans, RGB controllers, or legacy devices that require Molex power.
7. **Check All Connections**
 - Verify that all connectors are fully inserted and locked.
 - Ensure no cables are loose or obstructing fans.
8. **Power On and Test**
 - Connect the AC power cord to the SMPS.
 - Turn on the SMPS switch and start the PC to confirm all components receive power.

Component	Cable Used	Connector
Motherboard	ATX Power Cable	24-pin ATX Connector
CPU	EPS/CPU Power Cable	8-pin (4+4) CPU Connector
Graphics Card	PCIe Power Cable	6-pin / 8-pin / 6+2-pin PCIe Connector
SSD/HDD	SATA Power Cable	SATA Power Connector
Legacy Fans/Devices	Peripheral Power Cable	4-pin Molex Connector